

Re: Printer setup howto

Source: <http://linux.derkeiler.com/Mailing-Lists/Debian/2006-04/msg04429.html>

- *From:* "Roberto C. Sanchez" <roberto@xxxxxxxxxxxxxxxxxxxxxx>
 - *Date:* Sun, 30 Apr 2006 11:23:09 -0400
-

Csanyi Pal wrote:

Hello!

How can I setup margins correlated to the edges of A4 paper?

I have the printer HP Business Inkjet 1000 and use the hpjis driver to print.

If I use Gnome-cups-manager to setup the printer, and I print a test page therein with format paper of A4, then to check margin settings, I can use a ruler to verify that margin lines are printed at 0.5, 1, and 1.5 cm from the edge of the paper on all sides.

I verified these margin lines and get the results

from the top edge:

instead of 0.5 cm – 0.6 cm

instead of 1 cm – 1.1 cm

instead of 1.5 cm – 1.6 cm

from the right edge:

instead of 0.5 cm – 0.8 cm

instead of 1 cm – 1.3 cm

instead of 1.5 cm – 1.8 cm

from the bottom edge:

0.5 cm – don't show up !!!

1 cm – don't show up !!!

1.5 cm – 1.5 cm

from the left edge:

0.5 cm – 0.3 cm

1 cm – 0.8 cm

1.5 cm – 1.3 cm

How can I setup these margin lines to the right dimension?

Why don't show up the margin lines from the bottom edge of the paper at 0.5 cm and 1 cm?

If I do Align Cartridges... within HP Linux Imaging and Printing System window, then the printer print 2 pages and on the first page print at bottom corners 2 point:

Re: Printer setup howto

from the left edge 0.6 cm
from the right edge 0.6 cm
from the bottom edge 0.5 cm

Accordingly to this above the printer can print from all edge of paper A4 at 0.5 cm, but when I try to print say a draw.dxf from QCAD application, then the printer don't print at the bottom edge of A4 paper. Why don't print there?

I appreciate any advices!

I'm not sure what you are asking. Are you printing on Letter or A4 in the firstplace?

—Roberto

—

Roberto C. Sanchez
<http://familiasanchez.net/~roberto>

Attachment: signature.asc
Description: OpenPGP digital signature