

CD player does not send output to sound card

Source: <http://linux.derkeiler.com/Mailing-Lists/Fedora/2004-04/3847.html>

From: Ketut Parikesit (nyenkaden_at_plasa.com)

Date: 04/22/04

To: fedora-list@redhat.com

Date: Thu, 22 Apr 2004 08:54:18 +0700

Hi,

I'm totally newbie in Linux, and I'm having lots of problems but I'm determined to tackle them one at a time.

At the moment the problem that I'm having is with my CD-Rom drive. It doesn't seem to send the audio output to the soundcard. Whenever I put an audio CD in there, Fedora recognized it right away and plays the audio track, but no sound comes from the speaker. But when I rip the CD into the hard disk, the sound comes OK.

I can only get the sound if I plug the speakers directly into the headphone jack of the CD ROM drive. If I plug the speaker to the jack of the soundcard, I get no sound at all.

It could be some wiring problem (hardware problem), but it works with Windows XP.

Thanks in advance, and greetings from Bali.

=====
Netkuis Instan untuk wilayah Bandung (kode area 022) – SD,SMP,SMA berhadiah total puluhan juta rupiah...
periode I dimulai 1 April 2004
=====

--

fedora-list mailing list

fedora-list@redhat.com

To unsubscribe: <http://www.redhat.com/mailman/listinfo/fedora-list>