

Re: Netgear PS101 Print Server Setup with Fedora...

Source: <http://linux.derkeiler.com/Mailing-Lists/Fedora/2005-04/2842.html>

From: Peter Teuben (teuben_at_astro.umd.edu)

Date: 04/14/05

Date: Wed, 13 Apr 2005 23:01:56 -0400 (EDT)

To: For users of Fedora Core releases <fedora-list@redhat.com>

On Wed, 13 Apr 2005, Joseph Wheaton wrote:

> *I know many people have other netgear print servers set up with Fedora,*
> *but I cannot get mine to work. I have the IP address of the print*
> *server but I do not know which options to set or choose to set up the*
> *printer on my computer. Anyone have method to setting a netgear PS101*
> *up?*
>

i used to configure it from windows, before i read the tricks in linux.
here's my notes (recall there is a reset button on the box, if you've
misconfigured or don't remember it)

how to reset the print server:

```
ftp to the old address, login: ps????? (the device name at the bottom)
      no password, just hit enter
passive <-- make sure it's not passive mode anymore
get CONFIG
edit CONFIG <-- edit the IP,NM,GW etc.etc.
put CONFIG
get RESET this will trigger resetting with the new config file
get IPRESET <-- not sure if this is needed
```

```
<nemo/home/teuben7/hardware/netgear> ncftp -u ps516534 ps
NcFTP 3.1.5 (Oct 13, 2002) by Mike Gleason (ncftp@ncftp.com).
Connecting to 192.168.2.101...
Print Server Ready.
Logging in...
Password requested by 192.168.2.101 for user "ps516534".
```

```
Password required for user.
```

Fedora: Re: Netgear PS101 Print Server Setup with Fedora...

Password:

```
User logged in.  
Invalid command.  
Logged in to ps.  
ncftp /> ls  
200 CONFIG  
200 RESET  
200 DEFAULTC  
200 PSINF  
200 SETIP  
200 PASSRESET  
ncftp />
```

```
--  
fedora-list mailing list  
fedora-list@redhat.com  
To unsubscribe: http://www.redhat.com/mailman/listinfo/fedora-list
```