

# Re: TV out

---

*Source:* <http://linux.derkeiler.com/Mailing-Lists/Fedora/2006-09/msg01554.html>

---

- *From:* alan <[alan@xxxxxxxxxxxxxxxx](mailto:alan@xxxxxxxxxxxxxxxx)>
  - *Date:* Thu, 14 Sep 2006 08:51:16 -0700 (PDT)
- 

On Thu, 14 Sep 2006, Tod Merley wrote:

On 9/13/06, redhatdude@xxxxxxxxxxxxxxxx <[redhatdude@xxxxxxxxxxxxxxxx](mailto:redhatdude@xxxxxxxxxxxxxxxx)> wrote:

Hi,

I have a small TV that I'd like to connecto to my FC5 box to monitor the apache and ftp logs. I plugged it into the s-video connector in the back and all I get is a blue screen on the TV. Would someone tell me how to accomplish this, or point me to a how to on the web? My video card is integrated and shares memory with the computer. It's an ATI 9100.

Thanks in advance.

EJ

--

fedora-list mailing list

[fedora-list@xxxxxxxx](mailto:fedora-list@xxxxxxxx)

To unsubscribe: <https://www.redhat.com/mailman/listinfo/fedora-list>

Hi Ej,

1. Download the manual from the ATI site (ok, the 9200 is available – probably close enough).
2. Understand your TVs inputs and your ATI card outputs and which cord you need to properly connect the two. This must be right.
3. Check to see that your driver (Linux drivers available on the ATI site) is compatible with the video output feature you desire using your particular X version. I understand there are some issues with the most current drivers (ATI site).
4. From your Video Card Control Panel (should have installed this when installing the driver) see that the "enable video out" is enabled.

Do the open source ATI drivers support TV-Out?

Re: TV out

—

"Oh, Joel Miller, you've just found the marble in the oatmeal. You're a lucky, lucky, lucky little boy. 'Cause you know why? You get to drink from... the FIRE HOOOOOSE!"

– The Stanley Spudoski guide to mailing list administration

—

fedora-list mailing list

fedora-list@xxxxxxxxxxx

To unsubscribe: <https://www.redhat.com/mailman/listinfo/fedora-list>