

ERR in /proc/interrupts

Source: <http://linux.derkeiler.com/Mailing-Lists/Kernel/2003-09/7624.html>

From: Andreas Schwarz (*usenet.2117_at_andreas-s.net*)

Date: 09/30/03

To: linux-kernel@vger.kernel.org

Date: Tue, 30 Sep 2003 09:39:10 +0000 (UTC)

I get a very high ERR count in /proc/interrupts. If I move my USB mouse the number increases.

What does ERR mean? Nothing good, I suppose?

Kernel: 2.6.0-test6-mm1

/proc/interrupts:
=====

```

      CPU0
0: 1924793 XT-PIC timer
1: 9571 XT-PIC i8042
2: 0 XT-PIC cascade
5: 1561 XT-PIC ohci-hcd, eth1
8: 2 XT-PIC rtc
9: 0 XT-PIC acpi
10: 0 XT-PIC ehci_hcd, ohci-hcd, eth0
11: 31910 XT-PIC EMU10K1, uhci-hcd, uhci-hcd
14: 12483 XT-PIC ide0
15: 41 XT-PIC ide1
NMI: 0
LOC: 1924399
ERR: 15255
MIS: 0
```

--
AVR-Tutorial, über 350 Links
Forum für AVRGCC und MSPGCC
-> <http://www.mikrocontroller.net>
-

To unsubscribe from this list: send the line "unsubscribe linux-kernel" in the body of a message to majordomo@vger.kernel.org
More majordomo info at <http://vger.kernel.org/majordomo-info.html>
Please read the FAQ at <http://www.tux.org/lkml/>