

Re :- External HP SDLT Not detecting

Re :- External HP SDLT Not detecting

Source: <http://linux.derkeiler.com/Mailing-Lists/RedHat/2006-04/msg00394.html>

- *From:* "pp p" <alpha.piyush@xxxxxxxxx>
 - *Date:* Sat, 22 Apr 2006 00:24:10 +0530
-

Hi...

As per your suggestion, I have manually edited the /etc/rc.local file as following

```
echo "engage scsi" > /proc/scsi/cciss/cciss0
```

Problem has been resolved...

Thanks for the great help...

Regards.,

Piyush Trambadiya

Customer Support Engineer.

redhat-list mailing list

unsubscribe <mailto:redhat-list-request@xxxxxxxxx?subject=unsubscribe>

<https://www.redhat.com/mailman/listinfo/redhat-list>