

[SLE] USB external drive

Source: <http://linux.derkeiler.com/Mailing-Lists/SuSE/2004-08/4233.html>

From: Johan Sch (johansche_at_absamail.co.za)

Date: 08/31/04

Date: Tue, 31 Aug 2004 19:53:25 +0200

To: suse-linux-e@suse.com

Hi,

Running suse 9.1 – kernel 2.6.3–15mdk.(Mandrake 10.0 alternately). Installed and updated this last weekend. All this on a new pc. Do not know if my problem existed before the update.

When I transfer data to sda1 or 2 then the external drive light comes on and stays on. This hangs my pc too. Nothing works and the only recourse is to press the reset switch.

I remember sometime ago some discussions about hotplug/usb. That some application was to be re-installed from cd. I did not take that much notice of the problem because I did not have a problem.

Kindly please what was suggested to overcome this.

The new hardware may be suspected but works like a charm in Mandrake 10.0.

Thanks.

--

Johan Sch

Registered Linux User #330034

May this be a good day for learning

--

Check the headers for your unsubscription address

For additional commands send e-mail to suse-linux-e-help@suse.com

Also check the archives at <http://lists.suse.com>

Please read the FAQs: suse-linux-e-faq@suse.com