

RE: [SLE] APC UPS

Source: <http://linux.derkeiler.com/Mailing-Lists/SuSE/2005-02/2836.html>

From: Anders Norrbring (lists_at_norrbring.se)

Date: 02/28/05

To: <suse-linux-e@suse.com>

Date: Mon, 28 Feb 2005 15:28:05 +0100

> > *Hi all,*
> >
> > *Does anyone know how to set up an APC Back_UPS XS 1500 battery backup?*
> *This*
> > *APC ups works with a USB cable on the PC side connecting to an RJ-45*
> *plug in*
> > *the back of the ups. I'm using Suse 8.2. The apcupsd that comes with 8.2*
> *does*
> > *not seem to know how to handle the usb connection. Nor does the*
> *PowerChute I*
> > *downloaded from APC, it only seems to work with serial. I tried*
> *installing*
> > *rpm's from suse ftp for suse 9.0 and 9.1, but they have too many*
> *dependencies*
> > *on 8.2.*
> >
> > *Does anyone have an rpm for a newer version of apcupsd for suse 8.2?*

A much better alternative would be APC's own PowerChute application, it's downloadable from their website.

Anders

--

Check the headers for your unsubscription address

For additional commands send e-mail to suse-linux-e-help@suse.com

Also check the archives at <http://lists.suse.com>

Please read the FAQs: suse-linux-e-faq@suse.com