

## Re: USB bus fails to see devices

---

*Source:* <http://linux.derkeiler.com/Newsgroups/comp.os.linux.hardware/2007-07/msg00179.html>

---

- *From:* Haines Brown <[brownh@xxxxxxxxxxxxxxxxxxxxxxxxxxxx](mailto:brownh@xxxxxxxxxxxxxxxxxxxxxxxxxxxx)>
  - *Date:* Sun, 15 Jul 2007 12:38:16 GMT
- 

Rodney <[me@xxxxxxxx](mailto:me@xxxxxxxx)> writes:

On Sat, 14 Jul 2007 16:43:30 -0400, Haines Brown wrote:

Rodney <[me@xxxxxxxx](mailto:me@xxxxxxxx)> writes:

Does it look like the camera itself may have a hardware problem?

Well, that would be the next thing to check as you have already suggested you will do on your wife's computer.

I assume the camera still takes pictures and can display them ok on itself or else we wouldn't be discussing this topic.

If you have a windows machine to try it on, do so and, if it works, make sure it's unmounted properly before disconnecting it. I'm not sure what the terminology is for unmounting in Windows but there will probably be some icon in the tray for doing that, there always seems to some icon in the tray for stuff.

I borrowed a Windows laptop from my granddaughter to see if the device icon would pop up when the camera was plugged in. The result was negative. I've concluded the camera is broken. It takes and displays pictures OK, but apparently can't communicate with a computer via USB bus. Rather than simply replace the camera, I might look into a memory card reader.

---

Re: USB bus fails to see devices

Haines Brown, KB1GRM