

# Zaurus SL-C3000 rotation broken

**Source:** <http://linux.derkeiler.com/Newsgroups/comp.os.linux.portable/2005-07/0082.html>

---

**From:** Simon Kellett (*zoxed\_p\_at\_arcor.de*)

**Date:** 07/20/05

Date: Wed, 20 Jul 2005 22:10:54 +0200

My rotating screen Zaurus has screwed itself up (or maybe I did it :-). When I open it (landscape) it displays in portrait mode, then decides to rotate \*part\* of the screen to landscape. When I start an app it starts in portrait mode and works OK. But no way can I get back to using landscape mode.

The following do not work:

- reboot
- the rotate menu option
- an combination of opening and closing the lid, and physically rotating it.

I have not done many changes to the system: I have not touched the ROM, I have just imported my data, and installed a few extra programs: mplayer, kino2, ltris, brickout...

I have looked around the config files in /etc but can not find anything. /home/zaurus/Settings/display.conf looked promising but editing it seems to make no difference.

Any suggestions ?

--  
Simon Kellett, | Gentoo Linux, Fvwm, Firefox  
Darmstadt, Germany | Xemacs, Vm, Gnus